



REF.#	ITEM#	DESCRIPTION	QTY.	REF.#	ITEM#	DESCRIPTION	QTY.
1	27923	guard,rear,plastic	1	18	27930	board,led,off,switch,35k	1
2	27943	fan,brushless,dc,35k	1	19	27940	orifice,obe,35k	1
3	72811	cone,air,restraint,steel,35k	1	20	27939	holder,orifice	1
4	27933	thermocouple,assy	1	21	27921	base,upper,plastic,35k	1
5	72818	burner,assy,main,35k,38k	1	22	28806	board,power,supply,clp	1
6	27925	handle,carry,plastic	1	23	27960	cover,battery	1
7	27935	switch,high,limit	1	24	22815	board,control,main,clp	1
8	27951	electrode,ignition	1	25	27959	brkt,plastic,board,mount	2
9	72815	holder,flame,assy,35k	1	26	27922	base,lower,plastic,35k	1
10	72816	shield,radiation,assy,35k	1	27	27927	battery,35k	1
11	27965	barrel,assy,obe,35k	1	28	27924	door,battery,35k	1
12	27931	receptacle,power,supply	1	29	27956	hose and regulator	1
13	27950	bracket,valve,35k	1	*	27953	power supply cord	1
14	72804	valve,gas,assy,35k,38k	1	*	27954	battery connection wiring harness	1
15	28843	solenoid,valve,lockout	1	*	27926	button,Piezo,orange	1
16	27926	knob,valve	1				
17	27955	tubing,gas,burner,inlet,assy,35k	1				
						* Not shown on exploded parts view.	

When service or repair is required, it is recommended that you take your heater to an authorized Mr Heater Service Center.

When servicing or replacing batteries, please note:

- Do not service the heater with battery connected or plugged into a power outlet.
- Do not operate a damaged heater. Replace damaged cords immediately.
- Use only Mr Heater original battery type.

- Do not dispose of the batteries in a fire. The cell may explode. See "Battery Recycling Information" below.
- Do not open or mutilate the batteries. Released electrolyte is corrosive and may cause damage to the eyes or skin. It may be toxic if swallowed.
- Exercise care in handling batteries in order not to short the battery with conducting materials such as rings, bracelets and/or keys. The battery and/or conductor may overheat and cause burns.

Wiring Diagram (Model MH-35-CLP)

